

RX129-MP



SHR

Macho fijo recto rosca NPTF

HOSE DASH	ROSCA	REXON	IMPERIAL EASTMAN	DAYCO	PARKER
-04	1/8x27	RX129-04-02MP	HA-04-02MB	HU-04-02MP	10143-2-4
-04	1/4x18	RX129-04-04MP	HA-04-04MB	HU-04-04MP	10143-4-4
-04	3/8x18	RX129-04-06MP	HA-04-06MB	HU-04-06MP	10143-6-4
-06	1/4x18	RX129-06-04MP	HA-06-04MB	HU-06-04MP	10143-4-6
-06	3/8x18	RX129-06-06MP	HA-06-06MB	HU-06-06MP	10143-6-6
-08	1/2x14	RX129-08-08MP	HA-08-08MB	HU-08-08MP	10143-8-8
-12	3/4x14	RX129-12-12MP	HA-12-12MB	HU-12-12MP	10143-12-12
-16	1x1-1/2	RX129-16-16MP	HA-16-16MB	HU-16-16MP	10143-16-16

RX129-MJ



SHR

Macho fijo recto rosca JIC 37°

HOSE DASH	ROSCA	REXON	IMPERIAL EASTMAN	DAYCO	PARKER
-04	7/16x20	RX129-04-04MJ	HA-04-04MJ	HU-04-04MJ	10343-4-4
-06	9/16x18	RX129-06-06MJ	HA-06-06MJ	HU-06-06MJ	10343-6-6
-08	3/4x16	RX129-08-08MJ	HA-08-08MJ	HU-08-08MJ	10343-8-8
-08	7/8x14	RX129-08-10MJ	HA-08-10MJ	HU-08-10MJ	10343-10-8
-12	1-1/16x12	RX129-12-12MJ	HA-12-12MJ	HU-12-12MJ	10343-12-12

RX129-FJX



SHR

Hembra giratoria rosca JIC 37°

HOSE DASH	ROSCA	REXON	IMPERIAL EASTMAN	DAYCO	PARKER
-04	7/16x20	RX129-04-04FJX	HA-04-04NJ	HU-04-04FJ	10643-4-4
-04	1/2x20	RX129-04-05FJX	HA-04-05NJ	HU-04-05FJ	10643-5-4
-04	9/16x18	RX129-04-06FJX	HA-04-06NJ	HU-04-06FJ	10643-6-4
-06	9/16x19	RX129-06-06FJX	HA-06-06NJ	HU-06-06FJ	10643-6-6
-06	3/4x16	RX129-06-08FJX	HA-06-08NJ	HU-06-08FJ	10643-8-6
-08	3/4x16	RX129-08-08FJX	HA-08-08NJ	HU-08-08FJ	10643-8-8
-08	7/8x14	RX129-08-10FJX	HA-08-10NJ	HU-08-10FJ	10643-10-8
-10	7/8x14	RX129-10-10FJX	HA-10-10NJ	HU-10-10FJ	10643-10-10
-10	1-1/16x12	RX129-10-12FJX	HA-10-12NJ	HU-10-12FJ	10643-12-10
-12	1-1/16x12	RX129-12-12FJX	HA-12-12NJ	HU-12-12FJ	10643-12-12
-16	1-5/16x12	RX129-16-16FJX	HA-16-16NJ	HU-16-16FJ	10643-16-16